



## For a flexible menu

The Merrychef **eikon® e3** offers the versatility and adaptability a café, bar or bakery needs to meet customer demand at any time of day. Its unique three-tier cavity and rotating turntable allows for a broad range of cooking, from delicate croissants through to batches of breakfast items. An easyTouch® icon-driven touchscreen makes it easy to use even for untrained staff.



Reheat  
Danish pastries  
**80 seconds**



Open  
tuna panini  
**135 seconds**



Expanding your opportunities

[www.merrychef.com](http://www.merrychef.com)

## Bake, cook, toast and grill with only a Merrychef


The only high speed oven in the industry to include a turntable for even browning and a three-tier cavity for flexible cooking, allowing you to serve hot food on demand at any time of day, up to 5x faster than a conventional oven. UL certified ventless (if a catalytic converter is installed) and a patented cooling system to keep all walls cool-to-touch allows for easy front or back-of-house installation.

The easyTouch® icon-driven touchscreen allows untrained staff to produce professional results with every order whilst minimising training, reducing errors and food wastage.


### Precision Technology

Advance cooking technology® cooks up to 5x faster than a conventional oven combining two heat technologies of convection (3000W) and microwave (700/1000W) with a rotating turntable for fast, even heating (*other power levels are available to suit your requirements*).

Powerful uniform convection that gives perfect results, even with sensitive baked products.



Optional catalytic converter absorbs grease, helps eliminate food odours, keeps the oven clean and working efficiently.



The Merrychef eikon® e3 offers the versatility and adaptability for cafés, bars and bakeries to meet customer demands at any time of the day.

### Accessories

A range of accessories are available to use with a Merrychef eikon® e3 including:



Non-stick tray ideal for baking/roasting  
Part number: 40H0230



Griddled insert for turn-table plate  
Part number: 40H0240



Flat turn-table plate  
Part number:  
40H0347ANO



Cool down pan  
Part number: 32Z4043

The true versatility of the Merrychef eikon® e3 is realised through our unique Signature range of accessories that are available; from egg moulds to soup bowls.

View the full range at [merrychef.com/products/accessories](http://merrychef.com/products/accessories)

All cook times are based on using the **Merrychef eikon® e3**. Times may vary depending on food quality and portion size.